

CoastTec APC Unit Picture Reference Guide of Tier 1 Units

BX, BR, and BN Units and Battery Packs ending with “G”



BE Units ending with “G”
(ONLY BE650G, BE650G1 and BE750G)



BE/BN Units ending with the letter “M”, “M1” or “M2”



BR/BN Units ending with the letter “M2”, “MS”
or “MS2”



BGE or BGM Units (All BGE units accepted)



Network UPS (CP12142LI model)



SUA Rackmount Units (**ONLY SUA2200RM2U and SUA3000RMXL3U**)




SMT Units and Battery Packs (**All SMT models except: SMT750/SMT750C/SMT750US**)



SMX Units and Battery Packs (All SMX accepted)



SMTL Units (All accepted)



SCL Units (All accepted)



SRT Units (All SRT models accepted)





SRT Battery Packs (All SRT models accepted)



SRT Transformers (all accepted)



SURT Units (All SURT unit models except: SURT003, SURT005 and battery packs beginning with "SURT192")





SURT Transformers (AP9626 and AP9627)



UX Battery Packs (All accepted)



RBC Battery Trays

RBC22



RBC23



RBC24



RBC132, RBC157



RBC133



RBC43



RBC115, RBC116



RBC117



RBC118



RBC155



RBC141



RBC152



RBC143



RBC160, RBC161, RBC162



RBC44, RBC140



RBC88



RBC124, RBC130



RBC146-LI



M12USWH

